

## SilentFiber Wave Baffle Installation Guide:

**Step 1:** Locate the area in which your baffles will be hung

**Step 2:** Clean the provided cables with a damp rag or washcloth

**Step 3:** Run 3 cables through the ceiling grid (for 1 baffle), placed approximately 4 feet apart

**Step 4:** Starting with the center hanger, hold the baffle up to the bottom of the cable and connect center hanger with center cable

**Step 5:** Pull cable through the hanger until it is tight and at the appropriate height

**Step 6:** Repeat steps 3 & 4 for the second and third cable/hanger

**Step 7:** Using a leveling tool, check to make sure your baffle is even

**Step 8:** to loosen or detach the cable from the hanger, pinch in the plastic sides of the hanger



For more information:

[info@soundacousticsolutions.com](mailto:info@soundacousticsolutions.com)

[www.soundacousticsolutions.com](http://www.soundacousticsolutions.com)

Call toll free: [+1 \(877\) 399-9697](tel:+18773999697)

Follow us on social media:

